

	SERVICE	2-22
	INFORMATION	

Revised 12/5/14 by ET

SUBJECT: Walking tractors with PowerSafe® clutch : MAINTENANCE

After the first **30 hours** of use:

- Replace the external filter (B) with original item BCS 580.56208
- Check the fluid level using the gearbox dipstick (A), top-off if necessary.

Weekly:

- Check the fluid level using the gearbox dipstick (A), top-off if necessary.

Every **100 hours** of use or **once per year** (whichever occurs first)

- Remove magnetic cap (C) and drain fluid
- Replace the external filter (B) with original item BCS 580.56208
- Clean and reinstall magnetic cap (C)
- Re-fill with fluid until the dipstick (A) measures the appropriate level.

*** Approximately 2.4 quarts for BCS 739 and 2.75 quarts for BCS 749 & 750**

Compatible Universal Tractor Hydraulic/Transmission Fluid Specification Options:	
<ul style="list-style-type: none"> *VCE-WB 101 • CAT TO-2 • Allison C-4 • John Deere JDM J 20C • MF M1135, M1141, M1143, M1145 • Kubota UDT Fluid • Case New Holland MAT 3525 	<ul style="list-style-type: none"> • Case MS 1207, 1210 • Ford ESN-M2C86-B, ESN-M2C86- C, ESN-M2134-D • FNHA-2-C-201 • ZF TE-ML 03E, 06K, 17E * Universal/Heavy Duty Tractor Hydraulic/Transmission Fluid at NAPA, TSC, etc

